

**For instances where the floating shelf is not supported on the ends:**

- Attach two nuts together at the end of the threaded rod to create a lock
- Drill for the threaded rod into the stud(s)
- Using a drill with a socket adapter screw in the threaded rod into the stud
- Take off both nuts
- Apply construction adhesive to the threaded rod
- Slide the floating shelf onto the rods and let the adhesive dry

Tip: If a stud happens to land where a support cleat on the floating shelf is, take a chisel and remove the support. It should release after a couple of hits.

Tip 2: This can also be used in conjunction with the wall cleat that is provided by Abodian for extra support.

